

Symptoms	Solutions
Betapack 4 does not power up when power is applied.	<ol style="list-style-type: none"> <li>1. Check there is a mains voltage on the incoming supply terminal.</li> <li>2. Check the incoming supply terminals are all adequately tightened.</li> <li>3. Check the link cable between the control PCB on the front panel and the power PCB has not been disconnected or damaged.</li> </ol>
Betapack 4 is powering up but some or all of the channels are either not working or will not go to full output.	<ol style="list-style-type: none"> <li>1. Check the channel breakers are in the 'on' position.</li> <li>2. Check the channels have not had a Topset applied to them. Please see "Topset" for further details.</li> <li>3. If Betapack 4 is wired single phase check that the single-phase link bar has been fitted. If it is fitted check the screws are adequately tightened. Please see "diagram 3" for further details.</li> </ol>
Channels will switch on and off but are not able to be dimmed.	<ol style="list-style-type: none"> <li>1. The channel law has been set to switch. Please see "Dimmer Laws" for further information.</li> </ol>
The display is outputting a sequence of numbers after the Betapack 4 has been powered up.	<ol style="list-style-type: none"> <li>1. Channels have been soft patched.</li> <li>2. Please see "DMX Address" for further details.</li> </ol>
Unable to access any of the Betapack 4 functions.	<ol style="list-style-type: none"> <li>1. Betapack 4 has been locked.</li> <li>2. Please see "Lock/Unlock" for further details.</li> </ol>
Channel is remaining on all the time, even after disconnecting the controller and power cycling the Betapack 4.	<ol style="list-style-type: none"> <li>1. Triac has failed. Please contact your local service centre or contact Zero 88 technical support for further information</li> </ol>