


•

Building a Network




IP Addressing


DHCP









ZerOS Network Settings







Connecting to Capture





Example Systems



Using the Remote Apps





Windows IP Configuration

Internet Protocol Version 4 (TCP/IPv4) Properties

General

You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.

☐ Obtain an IP address automatically

☒ Use the following IP address:

IP address:

Subnet mask:

Default gateway:

☐ Obtain DNS server address automatically

☒ Use the following DNS server addresses:

Preferred DNS server:

Alternate DNS server:

☐ Validate settings upon exit

Advanced...

OK

Cancel

Zero 88 - ZerOS - Page 10 of 11

Printed: 03/07/2025

Wireshark