

By default, raising a playback's fader will automatically trigger the first cue within the playback. Lowering the fader, will by default automatically release the playback.

[Click here to find out more about triggering and releasing playbacks with their fader](#)

RELEASING PLAYBACKS

Once you have finished playing back cues it is important to release the playback. This stops the playback having any further control over the fixtures. When you lower a fader, the playback is automatically released.

You can also manually release a playback by holding **Clear** and pressing the Go button of the playback.

To release all the playbacks (and UDKs on FLX), except the Master Playback, hold **Clear** and press the **Fader Funct.** button. To manually release the Master Playback, hold **Clear** and press the Go button of the Master Playback.

On Solution consoles, you can press and hold **Clear** and tap **Memories** to release all playbacks except the Master Playback.

On ORB consoles you have some further options for releasing:

- **Shift** + **Release** - Releases all Playbacks & UDKs
- **Release** + **Stack** - Releases all Playbacks
- **Clear** + **Fader Funct.** - Releases all Playbacks EXCEPT the Master Playback
- **Sub** <Playback Number> **Release** - Releases the individual Playback via syntax